

COMMERCIAL RADAR INTERFACE



Integrate your radar with Rose Point ECS

Integrate your radar with Rose Point ECS

- Overlay the radar image on your chart with fully adjustable transparency
- Quickly and accurately identify the source of your radar returns
- Digital interface provides exceptional image quality and easy setup



Features

- Radar overlay in any chart view
- Traditional radar display using **Rose Point ECS'** split panels or full-screen on a secondary monitor
- Simultaneous display of AIS for checking fidelity between the radar and AIS vessel positions
- Optional control of radar from **Rose Point ECS**
- Traditional radar tools including Variable Range Marker (VRM), Extended Bearing Lines (EBL) and alarm zones
- North-up, course-up and heading-up display
- Optional recording of radar in voyage recordings

Easy Ethernet Connection

Interfaces your radar to your Rose Point ECS computer system.

Supports DHCP (Dynamic IPs), statically assigned DHCP leases, manually configured static IPs, and IPv4 Link Local Addressing.

Compatible Commercial Radars*

- Furuno FAR-21x7 series
- JRC JMA-5300 mark 2
- JRC/Alphatron JMA-610

Physical & Electrical Specifications

Dimensions: 9.6" L x 6.4" W x 1.8" H

Weight: 1 Lbs 10 Oz.

Electrical: 100-240V, 0.4Amp 50/60 Hz

**Some radar units may require a firmware update*

